



ENVIRONMENTAL AND SAFETY COMPLIANCE

AERIAL LIFT EMERGENCY RESCUE PROCEDURE
TO LOWER THE PLATFORM IN AN EMERGENCY or
TO RESCUE SOMEONE SUSPENDED IN A SAFETY
HARNESS

Scissors Lift

JLG2630ES

(inside the AHLC)

Using the Ground Level Controls:



1. Keep the RED Emergency Stop button pulled out.
2. Rotate the Key Switch clockwise to power Ground Controls.
3. Use the Toggle Switch to lower or raise the platform.
4. To turn off all power; push in the Emergency Stop button.

